

HIGH WIND POLICY/ WIND MONITORING

WIND SPEED	PROCEDURES	RESTRICTIONS
30 - 40 MPH	<p>Bridge Foreman/Facility Manager monitor wind speeds. Periodically travel bridge to visually assess bridge conditions and safety concerns for the travelling public.</p> <p>Message signs changed to: <i>HIGH WIND ADVISORY. USE CAUTION ON BRIDGE.</i></p>	None
40 - 50 MPH	<p>Bridge Foreman/Facility Manager monitor situation and notify Executive Director to seek direction.</p> <p>Message signs changed to: <i>HIGH WINDS . REDUCE SPEED ON BRIDGE.</i></p>	Escorted vehicles are to be individually assessed on the type of load.
50 - 60 MPH	<p>Bridge Foreman/Facility Manager or designee is on site. Bridge/Toll maintenance personnel are to be positioned at each end of the bridge to provide constant supervision of the crossing.</p> <p>Executive Director is to be notified.</p> <p>Message signs changed to: <i>HIGH WINDS . REDUCE SPEED TO 5 MPH</i></p>	Restrictions of recreational vehicles (motor homes and travel trailers), motorcycles, empty container type trucks as warranted by bridge foreman, Facility Manager or designee.
60 + MPH	<p>Executive Director or designee closes the Bridge. Appropriate authorities on both side of the bridge are to be notified.</p> <p>Message signs changed to: <i>BRIDGE CLOSED</i></p>	All Traffic